

4245 52nd St. SE Kentwood, MI 49512 • PH: 800-351-9776 www.coachhouseaccents.com

Painting Instructions

Typical Paints:

- Exterior Latex
- Polyurethane Paint

Key Considerations:

- Latex primers do not adhere well
- Surface roughening promotes adhesion
- Surface wipes do not promote adhesion (acetone, alcohol, etc.)

Preparation: (Regardless of the paint you choose, the following should apply)

- Carefully read and follow paint manufacturer's instructions
- · Work in a well-ventilated area
- Keep surface clean and dry
- · Carefully mask-off the reflective opaque Plexiglas "panes" of the window before painting.

Exterior Latex Paint Application:

- · Lightly sand surface with medium grit sand paper
- · Do not use primer!
- Apply two coats of exterior latex paint per paint instructions, allowing 4 to 6 hours drying time between coats

Polyurethane Paint Application:

- Lightly sand surface with Scotch Brite[™] by 3M
- Apply two component, Isocyanate Urethane Sealer (BASF Diamond #DS 30)
- · After 30 minutes, while the coating is still semi-wet, apply single stage Urethane top coat (BASF Solo)

This information is provided for your guidance only. We urge you to make all tests you deem appropriate prior to use. No warranties, either expressed or implied, including warranties of merchantability or fitness for a particular purpose, are made regarding products described or information set forth, or that such products or information may be used without infringing patents or others.